



MOBY

Position	Code	Spare part description
1	BMGMOPA.45673	Rear upper shell
2	BMGMOPB.45673	Rear lower shell
3	BMGWALA.45673	Front upper shell
4	BMGWALB.45673	Front lower Shell
5	PEDS501A.4650	Stator
6	PECR50C.4670	Rotor
7	PMCU1.4630	Bearing
8	PMCU12.4630	Bearing
9	PMCAC10.4630	Ring
10	BMG0780.4567	Front calotte
11	BMG0781.4567	Rear calotte
12	V4X65.5102	Screw
13	D4-D.5110	Nut
14	V4.8x9.5B.5101	Screw
15	PMD0576R03.4610	Gear
16	PMCBR.4630	Brass
18	PMDAP4.4610	Shaft
19	PMC55C.4630	Cotter
20	PPD0452.4540	Case
21	MO-B.2640	Spring
22	PMDCO5.4610	Gear
23	PMCSE18.4630	Seeger ring
24	PMP5.4610	Unlocking pin
25	R08C.5120	Washer
26	GOR-E1.5501	Packing
27	PMDICGM.46102	Gear
28	PMCS10.4630	Pin
29	PMCU3.4630	Bearing
30	PMCSE25.4630	Seeger ring
31	PMCS51.4630	Pin
32	PMDVR7.4610	Lead screw
33	PMD0943.4610	Female Screw
34	PMPU1.8003	Rear fork
35	CM-B.1630	Key lock
36	BPMMO.4540	Small lever
37	V4X5.5102	Screw
38	BMGMOSR01.45673	Unlocking handle
39	MO-S.2640	Spring
40	PMCS42.4630	Pin
41	V5X10C.5102	Screw
42	BPMW2.4540	Lower screw lid
43	32.010	Capacitor
44	PMDPA.4610	Plate
45	PMDSMP.4610	Rear bracket
46	PMD0782.4610	Rear fork
47	PMD0101.4610	Front Flask
48	C4VFMPM.2065	Female connector
49	C4VMPPM.8003	Male connector
51	PPD1038R02.4540	Vaschetta fincorsa
52	CMMO.8003	Wiring
53	D6A.5110	Nut
54	V6X18A.5102	Screw
55	V10X40.5101	Screw
56	V8X10.5102	Screw
57	V6.3X19.5101	Screw
58	V2.9X9.5-A.5101	Screw
59	R10.5120	Washer
60	R8.5120	Washer
61	D10.5110	Nut
62	V4X8.5105	Screw
63	R04E.5120	Washer
65	CMMO2.8003	Wiring
66	PPD0572.4540	Case
67	PPD1040R01.4540	End stroke dowel
73	MPFB3.2601	Wrapper
75	MMCT.2620	Thimble
76	MO-Z.2640	Spring
77	PPD1039R01.4540	Stroke-end Lid
78	BMG0984.45672	Stroke-end body
79	BMG0985.45672	Lock for limit switch
80	GOR12.5501	Packing
81	PPD0231.4610	Case
82	PMCAC41.4630	Ring