


SPIN11



Code SPIN11KCE

Description Kit spin1+flo2r-s+guida3mt

Position	Code	Spare part description
2	PPD1030.4540	Glass lid
3	PPD1104R03.4540	Fondo mot. "spokino" dis.1104
4	PPD1221.4540	Disc
5	PPD1033.4540	Cap
6	CA19.5320	Cable
7	PPD0530R04.4540	Testata superiore "sezionale m
8	PPD0531R03.4540	Lower stock
9	PPD0547R01.4540	Lower truck
10	PPD0548.4540	Upper truck
11	PPD0549.4540	Lever
12	PPD0550.4540	Lever
13	PPD0552R01.4540	Coperchio x ingr.rinvio "sez.mhouse" dis.0552
14	PPD0553R01.4540	Ingranaggio rinvio "sez.mhouse" dis.0553
15	PPD1087.4540	Collar
16	PMD1138.4610	Flask
17	PMD120103.4610	Profilo lam. sez.mhouse l=3000 Sp.10/10
18	PMD0542R01.4610	Flask
19	PMD0554.4610	Flask
21	PMD0528.4610	Lower catch
23	PMD0152B.4610	Flask
24	PMD0526.4610	Pull Rod
25	39.012	Wiring
26	SIA11	Encoder sia11 (spin10-gd0)
27	PMCCN1.4630	polypropylene rope
28	PMCCDR01.4630	mtd8m h=8mm drive belt
29	PMCS32.4630	Pin
30	PMCU103E.4630	Bearing
31	PMCU12E.4630	Bearing
32	CA71.5320	Wiring
33	SPA07	Motor
34	TRA-S4.1025	Transformer
35	SNA1	Control Unit
36	PFM-A.2213	Fuse holder
37	F1AR.2201	Fuse
38	MPSC.2601	Cable clamp
39	L8.6811	Lamp
40	CA5.5320	Cable
41	MO-G.2640	Spring
42	MO-X.2640	Spring
43	BMG1188.4567	Gear
44	V2.9X13.5101	Screw
45	V4.8X25.5101	Screw
46	V6X18.5102	Screw
47	V4.2X50.5101	Screw
48	V4.2X9.5.5101	Screw
49	V6.3X38.5101	Screw
50	V8X70B.5102	Screw
51	V8X35B.5102	Screw
52	V6X45.5102	Screw
53	V6X14A.5102	Screw
55	D6A.5110	Nut
56	D8.5110	Nut
57	R8.5120	Washer
58	R05.5120	Washer
59	R04E.5120	Washer
60	R06.5120	Washer
61	G4X8.5123	Grub screw
62	MA05.0901	Magnet
64	PPD1186R01.4540	Sleeve
65	R21.5120	Washer
67	MP004.2601	Supporto c.s. c/blocco l=9.5 "richco lcbs-6"
68	V4.2X9.5101	Screw
69	AF.5301	Wiring
71	R06B.5120	Washer