



SPIN

Code SN6041

Description Gear motor only "spin 4"

Position	Code	Spare part description
1	PPD1029.45401	Lid
2	PPD1030.4540	Glass lid
3	PPD1031R03.4540	Fondo motore spok
4	PPD1032.4540	Dowel
5	PPD1033.4540	Cap
6	PPD1036.4540	Knob
7	PPD0530R04.4540	Testata superiore "sezionale m
8	PPD0531R03.4540	Lower stock
9	PPD0547R01.4540	Lower truck
10	PPD0548.4540	Upper truck
11	PPD0549.4540	Lever
12	PPD0550.4540	Lever
13	PPD0552R01.4540	Coperchio x ingr.rinvio "sez.mhouse" dis.0552
14	PPD0553R01.4540	Ingranaggio rinvio "sez.mhouse" dis.0553
15	PPD1087.4540	Collar
16	PMD0540.4610	Flask
17	PMD0541.4610	Flask
18	PMD0542R01.4610	Flask
19	PMD0554.4610	Flask
20	PMD0527R02.4610	Upper mechanical stop
21	PMD0528.4610	Lower catch
22	PMD0544.4610	Plate
23	PMD0152B.4610	Flask
24	PMD0526.4610	Pull Rod
25	PMD121001.4610	Section
26	PMCU103E.4630	Bearing
26	PMD1434.8003	Ingr. sinteriz. sovrastampato
26	R30.5120	Washer
27	PMCCN1.4630	polypropylene rope
28	PMCCD1.4630	Belt
29	PMCS32.4630	Pin
31	PMCU12E.4630	Bearing
33	SPA05	Motor
34	TRA125.1025	Transformer
35	SNA4	Control Unit
36	PFM-A.2213	Fuse holder
37	F1.6AR.2201	Fuse
38	MPSC.2601	Cable clamp
39	L13 6811	Lampada sfera ch.e27 230V 40W
40	CA5.5320	Cable
41	MO-G.2640	Spring
42	MO-X.2640	Spring
43	MO-1132.2640	Spring
44	V2.9X13.5101	Screw
45	V4.8X25.5101	Screw
46	V6X18.5102	Screw
47	V6X55.5102	Screw
48	V4.2X9.5.5101	Screw
50	V8X70B.5102	Screw
51	V8X35B.5102	Screw
52	V6X45.5102	Screw
53	V6X14A.5102	Screw
54	V4.8X19.5101	Screw
55	D6A.5110	Nut
56	D8.5110	Nut
57	R8.5120	Washer
58	R05.5120	Washer
59	D4-D.5110	Nut
60	R06.5120	Washer
61	PMD1037.4610	Flask
62	MPP5.2601	Lamp holder
63	FER-001.1015	F.beads core l=28 de=19 di=10
64	V4X20.5102	Screw
65	CT200.5320	Wiring
66	SNA13	Card
67	V4.2X9.5101	Screw
69	R06B.5120	Washer