



TUB

Code TUB3500

Description Motor x sliding gates max3500kg

Position	Code	Spare part description
1	PMD1080R02.4610	Compl. scocca motorid. tub3500
2	PMD1079.4610	Leaf Case
3	PMD1086R04.4610	Piastra supp. centrale tub3500
4	PMD1164R03.4610	Flask
5	PMD1204R02.4610	Staffa supporto centrale TUB
6	PMD0774.4610	Right Flask
7	PMD0775.4610	Left Flask
8	PMD1084.4610	Plate
9	PMD1085.4610	Foundation plate
10	PMD0140.4610	Fastening rag bolt
11	PMD1065.4610	Unlocking pin
12	PMD1064.4610	Shaft
13	PMD0941.4610	Cog wheel
14	PMD0886.4610	Flask
15	PMD0885.4610	Flask
16	A500KIT	control unit 1motor
17	MICROIND.1617	Microswitch
18	MR1081/BR01	Motor
19	MR1081/AR01	Reducer
20	MICROI-N.1617	Microswitch
21	CA41.5320	Wiring
22	CA40.5320	Cable
23	GOR15.5501	Packing
24	CM-BL.1630	Lever
25	CM-B.1630	Key lock
26	ADTUB	Adhesive
27	MP0036.2601	Wire press
28	PMCPM1.4630	Cable-grip
29	PMCU91.4630	Bearing
30	MO-1066.2640	Spring
31	PMCBE10.4630	Unlocking lever
32	PMC1610.4630	Cotter
33	PMC108A.4630	Cotter
34	PMCSE32.4630	Seeger ring
35	PMCSE45.4630	Seeger ring
36	PMCSE25A.4630	Seeger ring
37	V5X10B.5102	Screw
38	V4X5.5102	Screw
39	V5X40.5102	Screw
40	V4X8.5105	Screw
41	V2.9X16.5101	Screw
43	V10X30.5101	Screw
44	G6X14.5123	Grub screw
45	G14X1.5.5123	Cap
46	G20X25.5123	Grub screw
48	D10B.5110	Nut
49	D12.5110	Nut
50	D12A.5110	Nut
51	R04F.5120	Washer
52	R04A.5120	Washer
53	R06A.5120	Washer
55	R12.5120	Washer
56	MMCT.2620	Thimble