



WINGO

Code WINGOKCE

Description Kit gearmotor for swing gates

Position	Code	Spare part description
1	BMGWAA.45673	Front upper shell
2	BMGWAB.45673	Front lower shell
3	BMGWPA.45673	Rear upper shell
4	BMGWPB.45673	Rear lower shell
5	BMG0778.4567	Front calotte
6	BMG0779.4567	Calotta post.mot.diam.80 allu.
7	PPD1244.4540	Unlocking key
8	CM-BG.1630	Ferrule
9	BPMWR02.45401	Sblocco compl."wingo" serigraf
10	BPMW2.4540	Lower screw lid
11	PMD0944.4610	Female Screw
12	PMDIC21R03.4610	Ingranaggio conico c/cod. z16
13	PPDCO7AR03.4540	Cuffietta "wingo" pa6+fv dis.0439
14	PPD0572.4540	Case
15	PMD0942.4610	Unlocking pin
16	PMDCO8R06.4610	Ingranag.m=1.25 z=34 di=24,7 bronzal "wingo" dis.0459
17	PMDVR5.4610	Lead screw
18	PMPU1.8003	Rear fork
19	BMG0503.4567	Gear
20	PMD0740.4610	Tang
21	PMDSMA.4610	Flask
22	PMDSMP2.4610	Rear Flask
23	PEDS451.4650	Stator
24	PECR45B.4670	Rotor
25	GOR-E1.5501	Packing
26	PMCBR.4630	Brass
27	PMCSE24.4630	Seeger ring
28	PMCU1.4630	Bearing
29	PMCAC10.4630	Ring
30	PMCU3.4630	Bearing
31	MO-B.2640	Spring
32	PMCS51.4630	Pin
33	PMC55C.4630	Cotter
34	PMCU12.4630	Bearing
35	M12V1.1850	Junction-box
36	MMCOI.2620	Thimble
37	30.010	Capacitor
39	MP0032.2601	Wire press
40	MP0033.2601	Ferrule
41	V4.2X13A.5101	Screw
41	V4.2X9.5101	Screw
42	V4X8.5105	Screw
43	V4X65.5102	Screw
44	V4.8X13.5101	Screw
45	V4.8X9.5-A.5101	Screw
46	V6.3X19.5101	Screw
47	V8X10.5102	Screw
48	V10X40.5101	Screw
49	D32.5102	Nut
50	D4-D.5110	Nut
51	D10.5110	Nut
52	R04E.5120	Washer
53	R08C.5120	Washer
54	R8.5120	Washer
55	R10.5120	Washer
56	PMCBR11.4630	Brass
57	V6X25.5102	Screw
58	PMD0528.4610	Lower catch
59	PMD0527R02.4610	Upper mechanical stop
60	D6.5110	Nut
61	PPD0415.4540	Supp. notolino serratura
62	PPD0414.4540	Nottolino serratura
63	PPD0413R01.4540	