



RUN

Code RUN1800

Description Motor. canc. scorr. 1800KG

Position	Code	Spare part description
1	PPD1252R01.4540	Parete supporto centrale "RUN"
2	14U450.0727	Capacitor
3	F6.3AR.2201	Fus.6,3A 5x20 sf ritard. 250V
4	PFM-B.2213	Fuse holder
5	V4.2x38.5101	Vite autofil. 4.2x38 TC+ UNI6954
6	CA1356.5320	Cablaggio centrale
7	FILTEMI001.1022	Filtro di rete 230V
8	D8.5102	Nut
9	BMG1248.45673	Coperchio fisso "RUN" ver.
10	TRA134.1025	
11	CA1357.5320	Cablaggio encoder
12	PPD1261.4540	Ventola porta magneti
13	PMD1358.4610	Boccola bloccaggio ventola diam. int.17mm
14	V6.3X19.5101	Screw
15	RUA1	Centrale ric. scorrevole RUN
16	V4X8.5105	Screw
17	SIA10	Encoder
18	PPD1262.4540	Supporto per scheda encoder
19	MA3x3.0901	Magnete al neodimio diam. 3x3
20	PPD1249.4540	Coperchio removibile "RUN"
21	PMD1054.4610	Screw
22	BMG1251.45673	Maniglia con camma di sblocco"RUN" vern.
23	MR1342	Mot. Simm. monofase 230V; 200W
24	PPD0955R01.4540	Side wall
25	PPD0957R01.4540	Unlock mechanism
26	21.105	Spring
27	V6.3X25.5101	Screw
28	V4.8x13-C.5101	vite autofil. 4.8x13 tcebi zn. b. dis. 1267
29	PPD0959R01.4540	Cam
30	PPD0960R01.4540	Lock flap door
31	PPD0956R01.4540	Box
32	PMD1259R01.4610	Vite senza fine B=3
33	GOR1257.5501	Guarnizione fondo mot.
34	PMCS10.4630	Pin
35	CM-B.1630	Key lock
36	PMD1340.4610	Molla per maniglia
37	V4X5.5102	Screw
38	PMCPM2.4630	Passacavo a membrana di=28
39	PMCPM.4630	Cable-grip
40	PPD1253.4540	Coperchio copri zanche "RUN"
43	PPD0601.4540	Lower stroke-end shell
44	MICROI.1617	Microswitch
45	PPD1195.4540	Packing
46	PPD0600.4540	Upper stroke-end shell
47	V2.9X9.5.5101	Screw
48	MO-D.2640	Spring
49	PPD0627.4540	Runner
50	BMG1247.45673	Base motore "RUN" vern.
51	PMD0886.4610	Flask
52	G6X14.5123	Grub screw
53	PMD0885.4610	Flask
54	GOR-L.5501	Packing
55	PMD1256.4610	Perno di sblocco RUN
56	PMCAC1.4630	Ring
57	MO-N.2640	Spring
58	PMCU3.4630	Bearing
59	PMCSE30.4630	Seeger ring
60	PPD1255.4540	Corona elicoidale RUN
61	PMD1258.4610	Fiangia per corona elicoidale
62	PPD0120.4540	Sleeve
63	PMC128.4630	Cotter
64	V6.3X22D.5101	Screw
65	PMD1260.4610	Albero condotto
67	D12.5110	Nut
68	R12.5120	Washer
69	PMD1341.4610	Piastra di fondazione RUN
70	D12B.5110	Nut
71	PMD0140.4610	Fastening rag bolt
72	D8.5110	Nut
73	PMCU10.4630	Bearing
74	GOR-M.5501	Packing
75	BMG1250.45673	Fiangia per alb. d'uscita "RUN" ver.
76	V6X15B.5102	Screw
77	PMD0628.4610	Coq wheel
78	R12C.5120	Washer
79	V10X12.5102	Screw
80	PPD1254.4540	Protezione per pignone "RUN"
81	GOR17.5501	Guar. OR 130x2mm NBR 70